

Classroom 4044 AV Instructions

Getting Started

- Touch the Crestron **touchscreen** to begin. You will now see the main menu. Sources (computer, laptop, Apple TV) are on the left-hand side of the panel. Room controls (lights, displays, etc.) are on the bottom row of the panel window.
- Select a source and adjust lights or cameras if desired.
- Once a source is selected, the displays will come on. You can also select to turn on/off either display.

Playing content from a flash drive or the cloud (Duke Box)

- For best performance for flash drives, plug in to the computer in the equipment cabinet (behind the teaching seat location.)
- To use Duke Box, log in as you would on your own computer and navigate to your desired folder/content.

Laptop input

- There is an HDMI cable in the rack drawer. HDMI to USB-C adapter is there as well. The system should automatically recognize your device once connected.
- You may also connect via Screen Mirroring via the Apple TV.

DVD

- Select **DVD/Blu-ray** as the source and Insert into the Blu-ray DVD player located in equipment cabinet.
- Touch and use the controls accordingly on the Blu-ray window remote on the touchscreen.

Apple TV

- Touch the Apple TV button on the left side of the main menu.
- Go to **Screen Mirroring** on your iPhone, iPad, or Mac laptop, and select DLSATV4044.
- Touch mirror and select “on”. It will mirror your device on the displays.

Shutting the System Down

- Log off and restart the computer if you have logged into any personal settings.
- If the last class of the day, touch Exit on the upper right side of the main menu and then select **Yes**.
- Do not forget to remove your tech (flash drives, DVDs, etc.)

Call **613-7249** if you need assistance.