Classroom 4045 AV Instructions

Getting Started

- Touch the Crestron touchscreen to begin.
 - o **Sources** (Computer, Laptop, Apple TV) are on the left-hand side of the panel.
 - o **Room Controls** (lights, projector, cameras, etc.) are on the bottom row of the panel.
- Select a source and adjust room controls, if desired.
- Once the projector is powered on, the rear display will mirror the source. You can also select to turn on/off the projector and display independently of one another.

Computer | Opening content from a flash drive or the cloud (Duke Box)

- Select Computer as the source.
 - o Flash Drives:
 - For best performance, plug directly into an open USB port on the computer in the equipment cabinet.
 - Duke Box:
 - Double-click the Duke Box shortcut on the desktop
 - Log in using your NetID and password, then navigate to your desired folder/content.

Laptop

- Select **Laptop** as the source.
- There is an HDMI cable on the teaching table. HDMI to USB-C adapter is in the equipment cabinet drawer. The system will automatically recognize your device once connected.
- If using an Apple Device (Macbook, iPad, or iPhone), connect wirelessly with Screen Mirroring via the Apple TV source (see Apple TV below).

DVD

- Select DVD/Blu-ray as the source.
- Insert the disc into the Blu-ray/DVD player located in equipment cabinet.
- Use the touchscreen controls to navigate the Blu-ray menu options.

Apple TV

- Select **Apple TV** as the source.
- Go to Screen Mirroring on your Macbook, iPad, or iPhone, and select DLSATV4045.
- Touch mirror and select "on". It will mirror your device on the displays.

Shutting the System Down

- Log off and restart the computer if you have logged into any personal settings.
- Do **not** forget to remove your tech (flash drives, DVDs, etc.)
- On the Crestron touchscreen:
 - Turn off displays.

Classroom 4045 AV Instructions

- o If the last class of the day, touch **Exit** on the upper-right side of the screen and then select **Yes**.
- o If there is a class after yours, do **not** exit out of the Crestron touchscreen. Please leave the system on.